

GORILLA POST

Magnetic Mounting System



TAMING THE URBAN JUNGLE
Your Delineator & Bollard Resource

Gorilla Post User Instructions – Toolless Magnetic Posts

Congratulations on your recent purchase of the Gorilla Post System. The system components include the metal mounting base plate, epoxy to permanently attach the plate to the concrete or asphalt subsurface, and the post or bollard.

Preparing Toolless Post or Bollard and Placing onto the Base Plate

- 1) Remove all the materials, paper or plastic, attached to the underside of the magnetic base during shipment. (image 1-A)
- 2) Once the base plate's epoxy has fully cured, the post or delineator can be lowered onto the plate. The magnetic pull is very strong and will first be felt when the base is about 4" above the plate. The post or delineator should couple to the plate so that the post is resting completely on the base plate. (image 1-B)
- 3) Place the post with the white directional indicator facing the direction of on-coming traffic, if any expected. (image 1-C)



image 1-A



image 1-B



image 1-C

Removal of the Toolless Post from the Plate

- 1) Grasp the top few inches of the tube, then push in the direction of the white directional indicator until the post decouples from the plate. (image 2-A & B)



image 2-A



image 2-B

Deployment Fails:



Hex or Wrong Bolts



Epoxy in Center Hole



No or Wrong Epoxy



Debris on Shim Magnet



Debris on Base Plate

